


Blade flag


Both blade flag sizes use the same steps. Your kit has the ground stake or the X base with water bag, whichever you chose.




1 Check the parts: pole sections, plus the X base bars, spigot and water bag, or the ground stake.




2 Join the poles. Push the sections together, the thin flexible section at the top.




3 Put the flag on. Slide the pole up into the blade flag's pole pocket until the top section bends into the curve.




4 Tension it. Pull the cord at the bottom of the flag down and hook it near the bottom of the pole.




5 Hard ground: cross the two base bars into an X and screw the spigot into the center.



6 Weigh it down. Slide the water bag over the spigot onto the X and fill it with water through the cap.



7 Soft ground: push the ground stake straight down into the grass or soil instead of using the X base.



8 Stand it up. Lower the bottom of the pole onto the spigot. The flag turns with the wind.

GOOD TO KNOW

- Use the ground stake on grass or soil, and the X base with its water bag on concrete, pavement or indoor floors.
- The flag is rated for wind of about 18 to 23 mph. Take it down in stronger wind.
- Poles and base pack into the carry bag.

CARE

- Wash by hand, or on a gentle machine cycle, in cool water with a mild detergent.
- Hang to dry, and make sure the flag is dry before you store it.
- Do not use bleach.