


Fabric pop up display


Shown on the 10 ft display. The 8 ft display sets up the same way. The frame opens in one piece.




- 1 Unpack.** Take the collapsed frame out of its bag and stand it upright.




- 2 Open it.** Pull the frame out to its full width, working from both sides.



- 3 Lock it.** Slide each locking bar between its hubs until it clicks.



- 4 Add the graphic.** Lay the frame on its back and spread the printed graphic over the front.



- 5 Wrap the ends.** Press the hook-and-loop edges onto the back edges of the frame, then stand the display up.



- 6 Done.** The graphic covers the front and both 12 in ends. The back of the frame stays open.

GOOD TO KNOW

- For indoor use.
- The frame and graphic pack into the black nylon carry bag.
- Shipping weight is about 29 lbs for the 10 ft and 24 lbs for the 8 ft.

IN THE BOX

- Frame + Graphic: the printed graphic with end caps, the aluminum frame and a black nylon carry bag.
- Printed Graphic Only: the graphic, for a frame you already own.